

# USER INSTRUCTION

# CEMSTAR INTERIOR

- 1 Thoroughly clean the area around the joints
- 2 Then wet the areas between the joints thoroughly
- 3 Then apply CEMSTAR interior in the gap using brush / Scrappers until it is compacted into the area between the boards
- 4 Once it is partially dry press-fix a 2 inch glass mesh over the joints and gently
- 5 apply CEMSTAR interior over the mesh which overlaps the joints on either side and leave it to dry completely.
- 6 After it is dry slightly sand over the top of the compound for smoothness or if other finishing work is to be done over it then continue doing it without sanding